

# M151

**DORMER**

- Sleeves Hardened and Ground
- Reduzierhülsen, gehärtet und geschliffen
- Reduceerhulzen, gehard en geslepen
- Cône de réduction
- Conos Morse endurecidos y cementados
- Casquilho Cone Morse Temperado e Rectificado



## M151

K=Ext. K1=Int. / K= Außenkegel K1= Innenkegel / K= uitw. K1= inw. / K=Ext. K1=Int. / k=Ext. K1=Int. / K=Cone Morse Ext. K1=Cone Morse Int.



Nr.	K = Nr.	K1 = Nr.	e-Code	Nr.	K = Nr.	K1 = Nr.	e-Code
10	1	0	M1511-0	52	5	2	M1515-2
21	2	1	M1512-1	43	4	3	M1514-3
31	3	1	M1513-1	53	5	3	M1515-3
41	4	1	M1514-1	54	5	4	M1515-4
32	3	2	M1513-2	65	6	5	M1516-5
42	4	2	M1514-2				